


ASSEMBLY INSTRUCTION





PARTS LIST




Сканировано с CamScanner

HARDWARE LIST


A 8 PCS	B 8 PCS	C 1 PC	D ∅ 4x14mm 1 PC	E ∅ 4x35mm 10 PCS
F ∅3x12mm 12 PCS	G ∅ 6x30 mm 4 PCS	H 1 PC	I 1 PC	J 2 PCS
K 4x12mm 2 SETS				


Please read instruction before you start assembling



Сканировано с CamScanner


3






A	B
4 PCS	4 PCS

4




G
∅ 6x30 mm
4 PCS

5




6




E
∅ 4x35mm
8 PCS

Сканировано с CamScanner

7




8




C	D
1 PC	Ø 4x16mm 1 PC

F	H	F	I	J
Ø3x12mm 2 PCS	1 PC	Ø3x12mm 6 PCS	1 PC	2 PCS

9



10



E	F	K
Ø 4x35mm 2 PCS	Ø3x12mm 4 PCS	Ø4x12mm 2 SETS



Сканировано с CamScanner